

Quick Start


Z41G7830813 18A

PHILIPS






PHILIPS



PHILIPS
TELEVISION




AAA






China



Singapore
Malaysia








Quick
Start
PHILIPS


www.philips.com/welcome
PHILIPS



PHILIPS

1






2
















2a


3



5




4




2b


③




④




⑤




3



HDMI





YPbPr & AUDIO L/R





AUDIO L/R & VIDEO IN






HDMI
HDMI 1
Blu-ray Disc



YPbPr & Audio L/R
Y Pb Pr L R
CVI
Y Pb Pr L R



AV-IN
R
L
VIDEO
R AUDIO L
OUT
VIDEO
OUT
DVD
VIDEO



PC IN
VGA
AUDIO
VGA



YPbPr & Audio L/R
75 Ω
ANTENNA
Y
Pb
Pr
L
R
CVI
AUX
ANTENNA
OUT
IN
TO TV
DVD
R / RW



AV-OUT
R
L
VIDEO
AUDIO
IN



1
2



SPDIF
OUT
AUDIO IN



IR LINK
IR IN


SERIAL
EXPRESS



2W 8
EXT. SPKR. OUT
AWG<16
2W 8Ω
BATHROOM
SPEAKER 8Ω
1W 8Ω
AWG<16


EXT. SPKR.
VOL. CTRL.
Rotary Type
Tact Type
VOL


2W 8
EXT. SPKR. OUT
EXT. SPKR.
VOL. CTRL.


VOL. CTRL.
SELECT
Tact Type
VOL
VOL. CTRL.
SELECT
Rotary Type
VOL. CTRL.
SELECT


4



5



Select your country
Slovenia
Spain
Sweden
Switzerland
Turkey
UK
Ukraine
Other
123
PHILIPS
OK
1
2
OK





www.philips.com/support

Non-contractual images. / Images non contractuelles. / Außervertragliche Bilder.

Specifications are subject to change without notice

www.philips.com